

MODULE POSITIONS FOR FDSM CAM

A	B	C	D	E	F	G	H	I	J
33"	32 1/2"	32"	31 1/2"	31"	30 1/2"	30"	29 1/2"	29"	28 1/2"

QUARTER-INCH MODULE POSITIONS FOR FDSM CAM

A-	B-	C-	D-	E-	F-	G-	H-	I-
32 3/4"	32 1/4"	31 3/4"	31 1/4"	30 3/4"	30 1/4"	29 3/4"	29 1/4"	28 3/4"

MODULE POSITIONS FOR M2 CAM

A	B	C	D	E	F	G	H	I
31 1/2"	31"	30 1/2"	30"	29 1/2"	29"	28 1/2"	28"	27 1/2"

MODULE POSITIONS FOR EM2 CAM

A	B	C	D	E	F	G	H	I	J	K	L	M
30"	29 1/2"	29"	28 1/2"	28"	27 1/2"	27"	26 1/2"	26"	25 1/2"	25"	24 1/2"	24"