

VISION QUICK START



The VISION Quick Start Guide is designed to get you up and shooting your new TenPoint crossbow with the latest electro-optic technology. For a complete understanding of its advanced features, please refer to the user manual and the instructional videos available on YouTube.

Inside the box, you will find the VISION Electro-optic, two batteries, a charger, a USB-C cable, a Picatinny mount for the optic, and supporting documents.

STEP 1:

Charging the 21700 battery (flat-top).

1. Connect the USB-C cable to the charger. Plug the standard USB end into any USB power supply rated at 1.2 A or higher.
2. The chrome-plated spring arm is the negative contact. Place the flat end (negative end) of the battery against the spring arm, then push the front, button end (positive end) into the front of the charger.
3. Repeat the same process for the second battery.
4. Note: The indicator(s) will start sequencing within 15 seconds to show the charging status. You can charge both batteries simultaneously.

STEP 2:

Installing the Picatinny mount on the VISION scope.

1. The Picatinny mount comes with four screws and an Allen wrench for attaching it to the VISION scope.
2. Position the mount so that it sits forward of the optic, with the MOA to the left from the shooter's perspective.
3. Install the four screws and tighten them using the provided Allen wrench.



STEP 3:

Mounting the VISION scope on your crossbow.

1. Place the VISION scope on your crossbow and adjust for the appropriate amount of eye relief.
2. Perform a visual inspection to ensure that the Picatinny mount is fastened properly to the Picatinny rail.



STEP 4:

Installing the battery in the VISION scope.

1. Locate the battery cap on the left side of the VISION scope.
2. Unscrew the cap and set it aside.
3. Insert the battery into the battery compartment, positive end first.
4. Reinstall the battery cap and tighten it 1/3 to 1/2 turn after the O-ring makes contact.

VISION QUICK START



Scan to View FAQs



Scan to View Instructional Videos

